

Re:mix Top Row Functions	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Top Row Function	Stop Grp 1	Stop Grp 2	Stop Grp 3	Stop Grp 4	Stop Grp 5	Stop Grp 6	Mod 1	Mod 2	Start/Stop + erase ptrn rec	Start/Stop + erase ptrn rec	Start/Stop + erase ptrn rec	Start/Stop + erase ptrn rec	Prev Preset (Mod 3)	Next Preset (Mod 4)	Macros toggle	Sends Toggle
Mod 1 Held	Vol -	Vol -	Vol -	Vol -	Vol -	Vol -			Pause pattern	Pause pattern	Pause pattern	Pause pattern				
Mod 2 Held	Vol +	Vol +	Vol +	Vol +	Vol +	Vol +			Overdub pattern	Overdub pattern	Overdub pattern	Overdub pattern	Global octave -	Global octave +	Global reverse	
Mod 1 + 2 Held	Mute/ Unmute	Mute/ Unmute	Mute/ Unmute	Mute/ Unmute	Mute/ Unmute	Mute/ Unmute			Erase paused pattern	Erase paused pattern	Erase paused pattern	Erase paused pattern				
Mod 3 Held									Step length page	Reverse page	Group page	Octave page			Set next tempo	
Mod 4 Held											Record length/ Select page	File page			Punch-in	Tap tempo