

Z Z Z Z :: start/end points, rate, direction

X				Pad's start point to 0
	X			Default start/end
		X		1/16th @ bpm start/end
			X	Pad's end point to 8
X	X			Random start point
		X	X	Random end point
	X	X		Random window
X		X		Double loop length
	X		X	Half loop length s> <e
X	X	X		Loop sync: a = b, b = c, c = a
	X	X	X	Loop sync: a = c, b = a, c = b
X	X		X	2x current rate (4x max)
X		X	X	0.5x current rate (0.125x min)
X			X	Toggle reverse playback
X	X	X	X	1.5x current rate (raise a fifth)

Z Z Z :: panning

-	X			Hard left
-		X		Hard centre
-			X	Hard right
-	X	X		Nudge left
-		X	X	Nudge right
-	X		X	Reverse panning
-	X	X	X	Random panning

Z Z :: levels + play/pause

-	-	X		0.125 lower
-	-		X	0.125 higher
-	-	X	X	Play (bright is paused)