

grid: 64

nb. see PARAMS > GRID to enable 64 grid + change brightness (default: 4-step varibright)

MAIN PAGE

A	B	C					→
REC L1	REC L2	REC L3			arc	arc	arc
							arc REC
				1	2	3	*f
				L	C	*r	P
				l/1	arp	z	z
				*lx	z	z	z
ALT			alt	z	z	z	z

BANK

DELAY PAGE

Left

Right

	A	+	+	+	+	A	←
	B	-	-	-	-	B	
s	C	rev	bmp	bmp	rev	C	s
a	EXT	l	f	f	l	EXT	a
v		e	d	d	e		v
e		v	b	b	v		e
s	level jump	e	c	c	e	level jump	s
ALT	fdbck jump	l	k	k	l	fdbck jump	